

22

Customer	:	CU-DAR001	Dart Helicopters Services	Drawing Name	:	ARMOR SHIELD			
Job Number	:	32690							
Estimate Number	:	12376							
P.O. Number	:	N/A		Part Number	:	D206667103A			
This Issue	:	5/25/2007	S.O. No. :	N/A	Drawing Number	:	DSI9326		
Prsht Rev.	:	NC			Project Number	:	N/A		
First Issue	:	N/A	Type	:	LANDING GEAR	Drawing Revision	:	A	
Previous Run	:	27980				Material	:	N/A	
Written By	:			Due Date	:	6/1/2007	Qty:	1	Um: Each
Checked & Approved By	:								
Comment	:								

Job Number:



1.0 DC DOCUMENT CONTROL



KS 07-05-29 ①



29629 ET 07 - 05 - 28

[illegible]

2-Apply Armor shield as per DSI 9326
A/R Armor Shield Batch: 103

A/R Armor Sheild Batch: 103813

PT 02-05-20

[illegible]

INSPECT SPRAY PAINT

J 0705-29 (1)

PACKAGING RESOURCE #1

[illegible]

Identify and pack for shipping as per PPP D206-667-103A

Location: _____

PPP Rev: _____

per 111-5265-597-105X

Rev Draft 7/5/28 89 L

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: 12 Date: 07/05/29
 QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Date: Friday, 5/25/2007 12:39:55 PM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: ARMOR SHIELD

Job Number: 32690

Part Number: D206667103A

Job Number:



Seq. #:

Machine Or Operation:

Description :

6.0

QC21

FINAL INSPECTION/W/O RELEASE



Comment: FINAL INSPECTION/W/O RELEASE

07/05/29

Job Completion



u 8-05-29

DART		TEL: 1-613-632-3336 FAX: 1-613-632-4443	
TRANSPORT CANADA APPROVAL 00849			
PN	D206-667-103	CHG	CHG002
DESC	Crosstube Fwd High	SIC	SH01-5
LOT	B29629	SIC	SR01304NY
MODEL	Bell 206L/L1/L3/L4	SIC	
MADE IN CANADA			

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

DART

DESIGN <i>PH</i>	DRAWN BY <i>PH</i>	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA	
CHECKED <i>J.J.</i>	APPROVED <i>A</i>	DRAWING NO. DSI 9326	REV. A SHEET 1 OF 1
DATE 06.02.14		TITLE ARMOR SHIELD	SCALE NTS
A	06.02.14	NEW ISSUE	

DART SERVICE INSTRUCTION

To further protect Dart crosstubes from mechanical damage in service, they may be treated with "Armor Shield" surface treatment.

INSTALLATION	CANADIAN STC	FAA STC
D205-596-101/-103/-105/-107	SH03-6	SR01742NY
D212-664-101/-201	SH01-9	SR01298NY
D412-664-203		
D206-667-101/-103/-201/-203	SH01-5	SR01304NY
D407-667-105/-205		
D058-676-101/-201	N/A	SR01018SE

To designate crosstubes with 'Armor Shield' add 'A' to the Part Number. For example, D206-667-101A is a D206-667-101 crosstube coated with Armor Shield. It is acceptable to apply the Armor Shield in regions shown in Figure 1 only. It is **NOT** acceptable to apply Armor Shield in the cuff and support/clamp regions.

1.0 To apply Armor Shield

- 1) Ensure the crosstube is appropriately finished in accordance with the relevant manufacturing drawing or Instruction for Continued Airworthiness (ICA).
- 2) Mask areas around supports and cuffs per Figure 1. Abrade paint finish in areas requiring protection using 320 grit sandpaper.
- 3) Clean/degrease surface of crosstube using Methyl Ethyl Ketone (MEK), 4105S Wash'n'Wipe Degreaser, or equivalent and wipe the surface to clean the entire area.
- 4) Apply 3 coats of Proform PF 746 or PF 746-1 to surface (apply additional coats when surface is dry, but not fully cured)
- 5) Allow 5 hours for coating to dry.
- 6) Apply 2 coats of Imron 500s Polyurethane Enamel clear + Dupont Imron Polyurethane Enamel Activator 192S (mix 3:1). Mix 15 minutes prior to application and allow 15 minutes before applying additional coats.

2.0 Armor Shield removal/re-application

To remove the Armor Shield coating or if damage to the coating and/or crosstube is observed during inspection.

- 1) Remove Armor Shield from the affected area using 80 grit sandpaper. To remove Armor Shield from larger areas, bead blasting has been determined to be the most effective technique.
- 2) Repair mechanical damage (within limits) to the crosstube and touch up finish in accordance with the relevant ICA.
- 3) Apply Armor Shield in accordance with Section 1.0 of these instructions.




FIGURE 1 - ACCEPTABLE REGIONS TO BE COATED WITH ARMOR SHIELD

SHOP COPY

RETURN TO
ENGINEERING

UNCONTROLLED COPY

SUBJECT TO AMENDMENT
WITHOUT NOTICE

WORK ORDER
NO. 32690

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-O-01

APPROVED

BY: *D. Shepherd*
D. SHEPHERD (DE # 02)

DATE: 06.02.14
CERT. NO.: SH03-6/SH01-9/SH01-5
ISSUE NO.: 3/3/3

Copyright © 2006 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.